

624L side by side refrigerator, silver with fruit & vegetable boxes, glass shelves, twist & serve icemaker & fast cooling boosts





Product Details

FEATURES

Flat door with integrated handles	Dual Crispers	SpillSafe Glass Shelves in the fridge & freezer	Quick Chill & Quick Freeze Functions
Two twist & amp; serve icemakers in freezer	Energy saving holiday mode	Electronic touch controls	LED lighting
Egg tray	Fridge and freezer door alarm	All Round Cooling	

BENEFITS

FreshSeal Crispers

Storing vegetables and fruit has never been so easy. Our dual FreshSeal Crispers offer a convenient storage solution for your fresh produce. They come in a great size to store fruit in one, and vegetables in the other.

Not just one, but two

Double your icemaking with two twist and serve ice makers - one in the door and one on the shelf. Simply fill the tray, let if freeze and then twist into the ice caddy, so you will always have plenty of ice for those summer drinks.

Contain the mess

Spills happen, but when they do, the world doesn't have to end. The Westinghouse SpillSafe™ glass shelves help with the mess by containing the spilt liquid to one shelf, so you have less to clean.

Chill out with Quick Freeze

Quick Freeze drops the temperature of the freezer fast, so you can keep your foods frozen, even after the big family shop.

Cool your groceries fast

Activate the Quick Chill function to cool your groceries fast, keeping them fresher for longer.

Inverter Technology

Our inverter technology helps your fridge hold a consistent temperature for energy efficiency.

All Round Cooling

Protects the quality of your food ensuring the most stable temperature and humidity in the whole fridge.



Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	side by side
Exterior door finish	Arctic silver
Handle design	integrated
Fridge door opening	right
Cooling system	frost free
Freezer door opening	left
Refrigerant	R600a

DIMENSIONS

Total height (mm)	1780
Cabinet height (mm)	1780
Total width (mm)	911
Cabinet width (mm)	911
Total depth (mm)	746
Cabinet depth (mm)	664
Depth door open 90degree (mm)	1191
Air space above cabinet (mm)	10
Food Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	407
Freezer Compartment Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	217
Total Capacity (L) - AS/NZS 4474.1 2007 (IEC 62552- 2015) *	624



ENERGY

Energy Star Rating -AS/NZS 4474.1 2007 (IEC 62552- 2015) * 4.5

Energy Consumption (kWh/year) - AS/NZS 4474.1 2007 (IEC 62552-2015) * 405

REFRIGERATOR SYSTEM

Controls	electronic (with display)
Controls location	external
Controls type	touch
Control functions	quick freeze function,holiday mode,quick chill
Door alarm	fridge and freezer

FOOD COMPARTMENT

SHELVING

Shelf material glass

Type of shelf spill safe shelf

CRISPERS

Crisper lid/shelf	glass
Crispers Runner system	rollers
Full width crisper	2
Crisper features	fully sealed

LIGHTING

Feature lighting LED

FOOD COMPARTMENT DOOR

OTHER PROPERTIES

Seals removable,mould resistant





FREEZER COMPARTMENT

ICE FACILITY	
Twist ice and serve	2
Ice Maker	Manual

SHELVING

Shelving	glass shelf
Type of shelf	spill safe shelf
Number of shelves	3

BASKET/DRAWER


Full width plastic basket	2

LIGHTING

Main light	LED	
man ngin	223	



Dimensions



Dimensions	Product Height (H)	Product Width (W)	Product Depth (D)
WSE6670BA	1780	911	746
WSE6670SA	1780	911	746
WSE6630SA	1780	911	746
WSE6630WA	1780	911	746
WSE6640BA	1780	911	746

Airspace	Side - both	Тор	Behind
WSE6670BA	10	10	50
WSE6670SA	10	10	50
WSE6630SA	10	10	50
WSE6630WA	10	10	50
WSE6640BA	10	10	50

IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product. © 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341. W_DIM_SxS_WSE6670-30-40_Oct21



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230 fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz